




CEL-200C-230U
Celeb 200 DMX Center Mount, Univ 230U

Spare Parts




1270305
CT-Xlr-Panel-Male-5-Pin



1270325
CT-Xlr-Panel-Female-5-Pin



1270356
CT-IEC Snap-In Inlet Fuseholder



1280021
No longer available
Relay DPDT 15A 12VDC.
Used in Rev A & B.
(Replace w/ same.)



1300019
Fuse 5x20 Cer Slowblow
3.15A/250V for 1270356



2010020
Bolt Hex-Head Steel 1/4-20 X2.75" BZ



2240013
Knob T 3/8-16 X 1-1/4" ST ZI "Kino"



2240017
Knob Lever 1/4-20 X 2.56 /53 Series



2240023
Knob Rnd Collet 6mm X 14.5mm Blk



2240024
Knob Nut Cover 14.5mm Blk



2240029
Knob T 1/4-20 #10 Kino Mount (wing)



2240025
Knob Cap 14.5mm Yel w/ Wht Line



2250003
Handle D 3x1-3/4" 10-32 Int Blk



4010002
Celeb DC/DC Converter Module



4010006
Celeb LED Diffuser Plate




4010009
Celeb Opto Encoder Module-Dimmer




4010015
Celeb DC Input 3-Pin XLR Harness. Used in Rev A & B. (Replace w/ same.)




4010020
Celeb Remote Board (NE8FAV). Used in Rev A & B. (Replace w/ same.)



4010023
Celeb Interface Control DMX



4010026
Celeb LED Panel Version 2. Replace w/ same.



PRT-CEP1

No longer available
Celeb 200 Panel
Retrofit Kit to replace
4010001 w/ 4010026



5260063

No longer available
Kino Mount #10
Loose Jaw



6400035

Celeb 200/400 DMX
Membrane Assembly



6800226

Dmx Jacks Conn Back



6800224

Celeb Relay Control
Board. Used in Rev C or
higher. (Replace w/
same.)



7010053

Celeb Center Mount
Assembly



FRB-C1

Celeb Frame Bracket
Assy #1




FRB-C2

Celeb Frame Bracket
Assy #2



GFR-CE2

Celeb 200 Gel Frame




LVR-CE290-P

Celeb 200 Louver/HP,
90°



MTP-LBC

Kino 41 Lollipop w/ Baby
Receiver Curve (16mm)



PRT-CE100

Celeb Series Access
"Slider" (4pk)



PRT-M10Y

Kino #10 Mount Kit-
Yellow



PRT-M11SY

Kino #10 Mount Spacer
w/ Spring Assembly



PRT-PWS-CE201

Repair Kit PWS Celeb
200/201. (Check PDF for
potential add'l parts)



PWC-L12/120

IEC Lock Power Cable,
12ft 120VAC