



DIV-L30X-120U
Diva-Lite 30 LED DMX, Univ 120U


Spare Parts



1160090
Ind Antenna Hinged
2.3DB 2.4GHz



1270305
CT-Xlr-Panel-Male-5-Pin




1270325
CT-Xlr-Panel-Female-5-Pin



1270367
CT XLR Panel Male 3-Pin
Cup



1270375
CT-IEC Snap-In Inlet
Cup



1290068
Switch SPDT Lit Red
Green Graphic



1290069
SW SPST 5ESH965 Base



1290071
SW 5ESH965 Cap Red
15.0mm



1290072
SW 5ESH965 Cap Green
15.0mm



1290073
SW 5ESH965 Cap Black
15.0mm




1290075
Switch Power Cap Only



1300019
Fuse 5x20 Cer Slowblow
3.15A/250V for 1320015



1320015
Fuseholder Screw Mount
5X20-0.187 Slot



1400008
Diva/Select 30 Platen



2010020
Bolt Hex-Head Steel 1/4-
20 X2.75" BZ



2240013
Knob T 3/8-16 X 1-1/4"
ST ZI "Kino"



2240023
Knob Rnd Collet 6mm X
14.5mm Blk



2240025
Knob Cap 14.5mm Yel w/
Wht Line



2240029
Knob T 1/4-20 #10
Kino Mount (Wing)



5160102
LED Control Bezel
USB cover #2




5260063
 No longer available
 Kino Mount #10
 Loose Jaw



5340004
 Diffuser KLED 30



6110114
 Diva LED Controller
 DC/DC Harness 4-Pin



6650043
 Diva 30 LED Fixture only.



6800228
 DMX Jacks - Isolated



6800235
 LED Encoder



6800251
 LED Controller w/ Timo
 Antenna




6820010
 LED Driver-150W
 (6800233 Support)



7010053
 Dive-Lite LED Center
 Mount Assembly



EXP-FXRS
 Fixture Wire
 Repair Kit Silver



LVR-SL390-P
 FreeStyle/Diva 30/31
 Louver/HP, 90°



MTP-H10
 Kino Handle Assembly
 #10



MTP-LBC
 Kino 41 Lollipop w/ Baby
 Reciever Curve (16mm)



PRT-CE100
 Celeb Series Access
 "Slider" (4pk)



PRT-FHSL30
 Select/Diva LED 30
 Fixture Silver (4pk)



PRT-FIX-SL3S
 Diva 30 LED Fixture Wire
 Channel Repair Kit/Silver



PRT-M10Y
 Kino #10 Mount Kit-
 Yellow



PRT-M11SY
 Kino #10 Mount Spacer
 w/ Spring Assembly



PRT-PWS-S39
 Power Supply Repair Kit



PRT-SC300
 Screws for Ballast Lid
 (100PK)



PWC-L12/120
 IEC Lock Power Cable,
 12ft 120VAC