



DIV-L30XU
Diva-Lite 30 LED DMX, Univ

Spare Parts




1160090
Ind Antenna Hinged
2.3DB 2.4GHz



1180069
Power Supply 39V/240W
100/240VAC 3 x 5"



1270305
CT-Xlr-Panel-Male-5-Pin




1270325
CT-Xlr-Panel-Female-5-Pin



1270367
CT XLR Panel Male 3-Pin
Cup



1270375
CT-IEC Snap-In Inlet



1290068
Switch SPDT Lit Red
Green Graphic



1290069
SW SPST 5ESH965 Base



1290071
SW 5ESH965 Cap Red
15.0mm



1290072
SW 5ESH965 Cap Green
15.0mm



1290073
SW 5ESH965 Cap Black
15.0mm




1290075
Switch Power Cap Only



1300019
Fuse 5x20 Cer Slowblow
3.15A/250V for 1320015



1320015
Fuseholder Screw Mount
5X20-0.187 Slot



1400008
Diva/Select 30 Platen



2010020
Bolt Hex-Head Steel 1/4-
20 X2.75" BZ



2240013
Knob T 3/8-16 X 1-1/4"
ST ZI "Kino"



2240023
Knob Rnd Collet 6mm X
14.5mm Blk



2240025
Knob Cap 14.5mm Yel w/
Wht Line



2240029
Knob T 1/4-20 #10
Kino Mount (Wing)



5160102
LED Control Bezel
USB cover #2




5260063
No longer available
Kino Mount #10
Loose Jaw



5340004
Diffuser KLED 30



6110114
Diva LED Controller
DC/DC Harness 4-Pin



6650050
Diva 30 LED Fixture only.



6800228
DMX Jacks - Isolated



6800235
LED Encoder



6800251
LED Controller w/ Timo
Antenna




6820002
LED Driver 150W
Version 3



7010053
Dive-Lite LED Center
Mount Assembly



EXP-FXRS
Fixture Wire
Repair Kit Silver




LVR-SL390-P
FreeStyle/Diva 30/31
Louver/HP, 90°



MTP-H10
Kino Handle Assembly
#10




MTP-LBC
Kino 41 Lollipop w/
Baby Reciever Curve (16mm)



PRT-CE100
Celeb Series Access
"Slider" (4pk)



PRT-FHSL30
Select/Diva LED 30
Fixture Silver (4pk)



PRT-FIX-SL3S
Diva 30 LED Fixture Wire
Channel Repair Kit/Silver



PRT-M10Y
Kino #10 Mount Kit-
Yellow



PRT-M11SY
Kino #10 Mount Spacer
w/ Spring Assembly



PRT-SC300
Screws for Ballast Lid
(100PK)



PWC-L12/120
IEC Lock Power Cable,
12ft 120VAC



PWC-L12/230
IEC Lock Power Cable,
12ft 230VAC