



**LED-120X-230U**  
FreeStyle 230 LED DMX Controller,  
Univ 120U

## Spare Parts




**1180075**  
Power Supply 48V/225W  
100/240VAC Non-L



**1270367**  
CT XLR Panel Male 3-Pin  
Cup



**1270383**  
IEC Screw Inlet  
Fuseholder



**1290068**  
Switch SPDT Lit Red  
Green Graphic



**1290069**  
SW SPST 5ESH965 Base



**1290071**  
SW 5ESH965 Cap Red  
15.0mm



**1290072**  
SW 5ESH965 Cap Green  
15.0mm



**1290073**  
SW 5ESH965 Cap Black  
15.0mm



**1290075**  
Switch Power Cap Only



**1300019**  
Fuse 5x20 Cer Slowblow  
3.15A/250V for 1270383



**2240023**  
Knob Rnd Collet 6mm X  
14.5mm Blk



**2240025**  
Knob Cap 14.5mm Yel w/  
Wht Line



**2250012**  
Handle D Offset  
4" x 1.5" 8-32 Int Blk



**5160172**  
LED Control Bezel  
USB Rubber Plug



**6110156**  
FreeStyle 120X  
Controller DC/DC  
Harness 6-Pin



**6110158**  
FreeStyle 120X  
Controller Output Tails



**6800228**  
DMX Jacks - Isolated



**6800235**  
LED Encoder



**6800262**  
LED Controller w/ Timo  
Antenna



**6820002**  
LED Driver 150W  
Version 3



**PRT-FET3**  
LED-120 Controller Feet  
(4pk)



**PRT-LXF100**  
X08-F125 Female  
Connector Assembly



**PRT-SC300**  
Screws for Ballast Lid  
(100PK)



**PWC-L12/230**  
IEC Lock Power Cable,  
12ft 230VAC