



LED-151X-120U
FreeStyle 151 LED DMX Controller,
Univ 120U

Spare Parts




1180069
Power Supply 39V/240W
100/240VAC 3 x 5"



1270367
CT XLR Panel Male 3-Pin
Cup



1270383
IEC Screw Inlet
Fuseholder



1290068
Switch SPDT Lit Red
Green Graphic



1290069
SW SPST 5ESH965 Base



1290071
SW 5ESH965 Cap Red
15.0mm



1290072
SW 5ESH965 Cap Green
15.0mm



1290073
SW 5ESH965 Cap Black
15.0mm



1290075
Switch Power Cap Only



1300019
Fuse 5x20 Cer Slowblow
3.15A/250V for 1270383



2240023
Knob Rnd Collet 6mm X
14.5mm Blk



2240025
Knob Cap 14.5mm Yel w/
Wht Line



2250011
Handle D Offset 3" x 1"
6-32 Int Blk



5160102
LED Control Bezel
USB cover #2



6110108
Select LED Controller
Output Harness



6110114
Select LED Controller
DC/DC Harness 4-Pin



6800228
DMX Jacks - Isolated



6800235
LED Encoder



6800251
LED Controller w/ Timo
Antenna



6820011
LED Driver 150W
(Replaces 6800250)



PRT-FET-L1
LED-151 Controller Feet
(4pk)



PRT-SC300
Screws for Ballast Lid
(100PK)



PWC-L12/120
IEC Lock Power Cable,
12ft 120VAC