



Spare Parts



PAN-F10
FreeStyle Mini LED Complete Fixture



1400021
LED Platen FreeStyle Mini 10



5160112
FreeStyle 10 Mating Plate



5160114
FreeStyle Frame Corner Left



5160115
FreeStyle Frame Corner Right




5160168
FreeStyle Mini 10 Platen Heatsink



5340033
Diffuser FreeStyle Mini 10



6260052
FreeStyle Mini 10 LED Harness



PRT-FS100
LED Fixture Accessory "Slider" (4pk)