



**TEG-450-120U**  
Tegra 4Bank DMX, Univ 120U

## Spare Parts



**1060029**  
Resvar 50k 0.1W Lnr  
Panel Knurl




**1170005**  
Filter EMI 4A  
120/250VAC w/ Wires




**1230032**  
Power Cord-Inline Switch  
16ft, 120vac




**1270305**  
CT-Xlr-Panel-Male-5-Pin



**1270325**  
CT-Xlr-Panel-Female-5-Pin



**1290013**  
SW-Toggle-Miniature-  
SPDT-5A



**1290023**  
SW-Wheel-3-Section-  
w/Lens



**1290062**  
Sw Rocker Mini SPST 1A  
12VDC



**1300020**  
FU-5X20-CER-Sloblow-  
4A/250V for 1320015



**1320015**  
Fuseholder Screw Mount  
5X20-0.187 Slot



**2010020**  
Bolt Hex-Head Steel 1/4-  
20 X 2.75" BZ



**2240013**  
Knob T 3/8-16 X 1-1/4"  
ST ZI "Kino"



**2240017**  
Knob Lever 1/4-20 X  
2.56 /53 Series



**2240023**  
Knob Rnd Collet 6mm X  
14.5mm Blk



**2240024**  
Knob Nut Cover 14.5mm  
Blk



**2240025**  
Knob Cap 14.5mm Yel  
w/Wht Line



**5260063**  
*No longer available*  
Kino Mount #10  
Loose Jaw



**2240029**  
Knob T 1/4-20 #10  
Kino Mount (wing)




**6260017**  
Tegra 4Bank  
Locking Harness



**6650036**  
Tegra 4Bank DMX Fixture  
Only



**6800204**  
Tegra 450 DMX Control  
Board



**6800218**  
Tegra 450 DMX  
Jacks Board



**6800500**  
TG1 Tegra  
Ballast Board



**LVR-T490-P**  
*No longer available*  
Tegra 4Bank  
Louver/HP, 90°



**MTP-LB**  
Kino 41 Lollipop w/ Baby  
Reciever (16mm)



**PRT-FIX-T4H**  
Tegra 4Bank Hinge  
Repair



**PRT-HLC**  
Kino Locking  
Lamp Connector, 600V



**PRT-M10Y**  
Kino #10 Mount Kit-  
Yellow



**PRT-M11SY**  
Kino #10 Mount Spacer  
w/ Spring Assembly



**PRT-SC300**  
Screws for Ballast Lid  
(100PK)

**Lamps:**



**488-K32-S**  
4ft Kino KF32



**488-K55-S**  
4ft Kino KF55